

BAK-UP USA

INSTALLATION GUIDE

BMW R1200GS DRIVER'S BACKREST 07 & UP

- 1. Remove the pillion seat and turn it upside down.**
- 2. Install the (4) four 6mm well nuts in the (4) four holes in the bottom of the pillion seat.**
- 3. Place your new backup backrest over the front of the pillion seat so that the holes in the backrest align with the well nuts.**
- 4. Start the screws in the (2) two back holes and leave them loose.**
- 5. Slide the (2) two spacers under the front to align with the front holes in the bracket and install the screws.**
- 6. Tighten all (4) four screws and re-install the pillion seat on the bike.**
- 7. Adjust to your liking.**

GET ON YOUR BIKE AND RIDE !

****PERIODICALLY** CHECK SCREWS ON PADS BECAUSE VIBRATION MAY CAUSE SCREWS TO LOOSEN**