

# **BAKUP-USA**

## **INSTALLATION GUIDE**

### **BMW 1200GS ADVENTURE DRIVER'S BACKREST 07 TO CURRENT**

1. Remove the pillion seat and turn it upside down.
2. Install the four (4) 6mm well nuts (provided) in the four (4) holes in the bottom of the pillion seat.
3. Place your new backrest over the front of the pillion seat.
4. Start the screws in the two (2) back holes and leave them loose.
5. Slide the two (2) spacers (provided) under the front to align with the front holes in the bracket, and install the screws.
6. Tighten all four (4) screws and re-install the pillion seat on the bike.
7. Adjust to your liking.

**GET ON YOUR BIKE AND RIDE !**

**\*\*PERIODICALLY\*\* CHECK SCREWS ON PADS BECAUSE VIBRATION MAY CAUSE SCREWS TO LOOSEN**