

BAKUP – USA

INSTALLATION GUIDE

KAWASAKI VULCAN 1700 NOMAD/VOYAGER DRIVER'S BACKREST

- 1. Remove the pillion seat from your bike and place it upside down on a workbench.**
- 2. Using a 10mm wrench remove the (2) two nuts and the bracket from the bottom of the pillion seat.**
- 3. Place your backrest over the front of the pillion seat and the (2) two mounting holes over the studs for the pillion seat bracket.**
- 4. Re-install the pillion seat bracket on top of the backrest bracket.**
- 5. Install the (2) two rubber bumpers (provided with your backrest) on top of the (2) two rubber bumpers on the bottom front on the pillion seat.**
- 6. Re-install the (2) two nuts and tighten.**
- 7. Re-install the pillion seat on the bike and adjust to your liking.**

GET ON YOUR BIKE AND RIDE !

****PERIODICALLY** CHECK SCREWS ON PAD BECAUSE VIBRATION MAY CAUSE THEM TO LOOSEN –
THANKS**