

BAKUP – USA

INSTALLATION GUIDE

Suzuki Boulevard C50 Driver's Backrest FA & HO

1. Remove the pillion seat.
2. Remove the two (2) screws that hold the forward bracket for the pillion seat.
3. Place your backrest under the bracket for the pillion seat so that all holes align.
4. Re-install the screws.
5. Re-install the pillion seat.
6. Adjust your backrest to your liking.

GET ON YOUR BIKE AND RIDE !

****PERIODICALLY** CHECK SCREWS ON PAD BECAUSE VIBRATION MAY CAUSE THEM TO
LOOSEN – THANKS**