

BAKUP-USA

Installation Guide

**Suzuki Boulevard M50 Driver's Backrest
FA**

- 1. Remove your pillion seat.**
- 2. Remove the two screws that attach the rear bracket of the driver's seat.**
- 3. Place your backrest so that the holes align with the holes where the screws were.**
- 4. Install the two screws that are provided with your backrest.**
- 5. Re-install the pillion seat.**
- 6. Adjust to your liking.**

GET ON YOUR BIKE & RIDE !

****PERIODICALLY** CHECK SCREWS ON PADS BECAUSE VIBRATION MAY CAUSE SCREWS TO LOOSEN**