

# BAKUP-USA

## INSTALLATION GUIDE

### BMW R1100-1150RT POLICE DRIVERS BACKREST

1. REMOVE THE SEAT & THE (2) ADJUSTMENT BLOCKS FOR THE REAR SEAT.
2. REMOVE THE (2) BOLTS FOR THE FRONT SIDE BAG SUPPORTS (1 ON EACH SIDE)
3. POSITION YOUR BACKREST SO THAT THE MOUNTING HOLES ALIGN WITH THE SADDLE SUPPORT BRACKET HOLES. (*NOTE: BE CAREFUL NOT TO PINCH ANY WIRES*).
4. REINSTALL THE BOLTS.
5. REINSTALL YOUR SEAT SUPPORTS & SEAT.
6. ADJUST TO YOUR LIKING

**GET ON YOUR BIKE & RIDE !**

**\*\*PERIODICALLY\*\* CHECK THE SCREWS ON PADS BECAUSE VIBRATION MAY CAUSE SCREWS TO LOOSEN**