



BAK-BMW
R1200GS-Driver

BAKUP-USA

INSTALLATION GUIDE

BMW 1200GS DRIVER'S BACKREST- 06

1. Place your bike on the center stand.
2. Remove pillion seat and the luggage rack.
3. Remove the plastic cover plate that is under the pillion seat (6-screws on top).
4. Remove the (2) screws (1 on each side) just to the rear of the driver seat.
5. Place the spacers that are provided with your backrest in the holes. NOTE: that the spacers are marked right and left.
6. Place your backup backrest on the bike so that the holes align, install screws that are provided with your backrest and tighten.
7. Cut out the template that is attached with a pair of scissors.
8. Tape the template to the front edge of the plastic cover plate that was removed earlier making sure that the top edge is aligned, then mark the bottom edge.
9. Using a pair of tin snips, cut away the plastic that is exposed below the template.
10. Repeat steps 2 & 3 in reverse order. Adjust to your liking.

GET ON YOUR BIKE & RIDE

!PERIODICALLY** CHECK SCREWS ON PADS BECAUSE VIBRATION MAY CAUSE SCREWS TO LOOSEN**