

## BAKUP-USA INSTALLATION GUIDE BMW 1200GS DRIVER'S BACKREST- 06

- 1. Place your bike on the center stand.
- 2. Remove pillion seat and the luggage rack.
- 3. Remove the plastic cover plate that is under the pillion seat (6-screws on top).
- 4. Remove the (2) screws (1 on each side) just to the rear of the driver seat.
- 5. Place the spacers that are provided with your backrest in the holes. NOTE: that the spacers are marked right and left.
- 6. Place your bakup backrest on the bike so that the holes align, install screws that are provided with your backrest and tighten.
- 7. Cut out the template that is attached with a pair of scissors.
- 8. Tape the template to the front edge of the plastic cover plate that was removed earlier making sure that the top edge is aligned, then mark the bottom edge.
- 9. Using a pair of tin snips, cut away the plastic that is exposed below the template.
- 10. Repeat steps 2 & 3 in reverse order. Adjust to your liking.

## GET ON YOUR BIKE & RIDE

!\*\*PERIODICALLY\*\* CHECK SCREWS ON PADS BECAUSE VIBRATION MAY CAUSE SCREWS TO LOOSEN