

# **BAKUP-USA**

## **Installation Guide**

BMW K1200GT – K1300GT Driver's

Backrest Models 06-11

Subframe 06 is different from 07-11

- **Place your Bike on the center stand.**
- **Remove Passenger and Driver Seat.**
- **Remove height adjustment blocks for the driver's seat.**
- **Place your backrest so that the (4) holes align with the holes for the height adjustment blocks in the frame.**
- **Re-install the height adjustment blocks using the (4) screws provided. Re-install driver and passenger seats.**
- **NOTE: You may have to pull forward on the backrest to get the passenger seat on.**
- **Adjust to you liking.**

***GET ON YOUR BIKE AND RIDE!***