

BAKUP-USA

Installation Guide

BMW K1200LT Driver's Backrest

1. Tilt driver's seat up.
2. Locate and remove the two allen bolts and washers.
3. **Place** the backrest in position, correctly aligning bracket feet to bolt holes.
4. **Attach with existing bolts. Do not use washers.**
5. **Return seat to original position. Adjust** your Backrest *to your preference –height, fore, and aft positions.*

GET ON YOUR BIKE AND RIDE!