

# **BAKUP-USA**

## **Installation Guide**

### **BMW R1100/1150RT Driver**

- 1. Remove the rider and passenger seats.**
- 2. Remove the two locating ramps brackets for the rear of the rider's seat and set aside.**
- 3. Using a 10mm wrench, remove the two (2) 10mm bolts to frame and install the backrest (one each side) using the same bolts to reinstall and torque the bolts to factory specifications.**
- 4. Reinstall the seats and adjust to your liking.**

**\*Note**

**It may be necessary to compress the front of the rear seat to insure that the bracket does not interfere with the seat cover on installation.**

***GET ON YOUR BIKE AND RIDE!***

***TOOLS NEEDED: 4mm Allen Wrench (included in RT tool kit) & 10mm Socket***