

BAKUP-USA

Installation Guide

BMW 1200CL DRIVER'S BACKREST

- 1. Remove two 10mm nuts holding down the driver's seat.**

Non Heated Seats

- 2. Install your backrest aligning holes in the bracket with holes in the frame of the driver's seat.**

Heated Seats

Install your backrest maneuvering the backrest underneath the wire going to the back heated seat so the wire is not pinched between the bracket, frame and seat. Align holes in the bracket with the holes in the frame of the driver's seat.

- 3. Reinstall the driver's seat positioning the two studs on the seat through the backrest bracket and holes in the frame, reinstall the two 10mm nuts torque to factory specifications.**
- 4. Adjust forward/backward, up/down to your liking. *We've got your back!***

GET ON YOUR BIKE AND RIDE!