

BAKUP-USA

Installation Guide

**BMW 1200GS DRIVER'S BACKREST
06 MODEL ONLY**

1. Place your bike on the center stand.
2. Remove Pillion seat and luggage rack.
3. Remove the plastic cover plate that is under the pillion seat (six screws on top).
4. Remove the two screws (one on each side) just to the rear of the driver's seat.
5. Place the spacers that are provided with your backrest in the holes.
6. Place your backrest on your bike so that the holes align. Install the screws that are provided with your backrest and tighten.
7. Cut out the template that is attached with a pair of scissors.
8. Tape the template to the front edge of the plastic cover plate that was removed earlier making sure that the top edge is aligned, then mark the bottom edge.
9. Using a pair of tin snips, cut away the plastic that is exposed below the template.
10. Repeat steps 2 and 3 in reverse order.
11. Adjust to your liking.

GET ON YOUR BIKE AND RIDE!