

# **BAKUP-USA**

## **INSTALLATION GUIDE**

### **BMW F-800GS PASSENGER**

1. **PLACE YOUR BIKE IN A SAFE PLACE.**
2. **REMOVE THE (2) SCREWS IN THE REAR OF THE PASSENGER GRAB HANDLES. ALSO REMOVE THE (2) SCREWS DIRECTLY BEHIND THE GRAB HANDLE SCREWS.**
3. **PLACE THE SPACERS PROVIDED, SHORT SPACER ON TOP OF THE GRAB HANDLES, LONG SPACERS OVER THE REAR HOLES.**
4. **SET THE BACKREST BRACKET ON TOP OF THE SPACER SO THAT THE HOLES IN THE BRACKET ALIGN WITH THE HOLES IN THE SPACERS.**
5. **INSTALL THE (4) SCREWS PROVIDED & TIGHTEN.**
6. **ADJUST FORWARD/BACKWARD, UP/DOWN TO YOUR LIKING.**

**GET ON YOUR BIKE & RIDE !**

**\*\*PERIODICALLY\*\* CHECK THE SCREWS ON PADS BECAUSE VIBRATION MAY CAUSE SCREWS TO LOOSEN**