

BAKUP-USA

INSTALLATION GUIDE

BMW F-800GS PASSENGER

1. PLACE YOUR BIKE IN A SAFE PLACE.
2. REMOVE THE (2) SCREWS IN THE REAR OF THE PASSENGER GRAB HANDLES. ALSO REMOVE THE (2) SCREWS DIRECTLY BEHIND THE GRAB HANDLE SCREWS.
3. PLACE THE SPACERS PROVIDED, SHORT SPACER ON TOP OF THE GRAB HANDLES, LONG SPACERS OVER THE REAR HOLES.
4. SET THE BACKREST BRACKET ON TOP OF THE SPACER SO THAT THE HOLES IN THE BRACKET ALIGN WITH THE HOLES IN THE SPACERS.
5. INSTALL THE (4) SCREWS PROVIDED & TIGHTEN.
6. ADJUST FORWARD/BACKWARD, UP/DOWN TO YOUR LIKING.

GET ON YOUR BIKE & RIDE !

****PERIODICALLY** CHECK THE SCREWS ON PADS BECAUSE VIBRATION MAY CAUSE SCREWS TO LOOSEN**