

# **BAKUP-USA**

## **Installation Guide**

### **HONDA 1800S & RETRO VTX Driver's Backrest**

1. Remove your pillion seat and place it upside down on a table or workbench.
2. Remove the (2) two bolts that hold the front bracket on the bottom of the pillion seat.
3. Place your backrest over the front of the pillion seat so that the holes are aligned with the holes of the front bracket. (The seat bracket goes between the seat and the backrest).
4. Install the screws provided with the backrest.
5. Re-install the seat.
6. Adjust to your liking!

***GET ON YOUR BIKE AND RIDE!***