

# **BAKUP-USA**

## **Installation Guide**

### **Suzuki Boulevard C90 Driver's Backrest FA & HO**

- 1. Remove your pillion seat.**
- 2. Remove the two screws that attach the rear bracket of the driver's seat.**
- 3. Place your backrest so that the holes align with the holes where the screws were.**
- 4. Re-install the two screws.**
- 5. Re-install the pillion seat.**
- 6. Adjust to your liking.**

***GET ON YOUR BIKE AND RIDE!***