

BAKUP-USA

Installation Guide

Yamaha V-Star 650 Classic Driver's Backrest

1. Remove the pillion seat.
2. Remove the screws to the rear of the rider's seat.
3. Position your backrest so that the tongue will lay between the two screws in the pillion bracket and the holes aligned with the bolt holes to the rear of the driver's seat.
4. Install the screws provided with your backrest.
5. Reinstall the pillion seat.
6. Adjust the height to your liking.

GET ON YOUR BIKE AND RIDE!