

BAKUP-USA

Installation Guide

Suzuki Intruder VS800GL Driver's Backrest HO

1. Remove (2) two screws philip's head (on each side) to the rear of the gas tank.
2. Remove the rider's seat.
3. Remove the two (2) philip's head screws in front of the passenger seat.
4. Put your backup backrest in place by aligning the holes at the base of the bracket with the holes (being careful not to pinch any of the wiring). Install the (2) two screws supplied with your backup.
5. Re-install the rider's seat and screws. Adjust the height to your liking.

GET ON YOUR BIKE & RIDE !

****PERIODICALLY** CHECK SCREWS ON PADS BECAUSE VIBRATION MAY CAUSE SCREWS TO LOOSEN**