

# **BAKUP-USA**

## **INSTALLATION GUIDE BMW K1600GTL DRIVER'S BACKREST**

- 1. Remove the driver seat and place upside down on a work bench.**
- 2. Remove the four (4) bumpers shown in figure 1.**
- 3. Using a 1/2" or 12.5mm drill bit, (be careful to hold the drill center while drilling) drill out the four (4) holes as shown in figure 2.**
- 4. Install the four (4) well nuts provided with your backrest as shown in figure 3.**
- 5. Starting from the rear of the seat slide the backrest over the seat so that the holes in the backrest align with the well nuts. Install the four (4) screws and bumpers provided with your backrest as shown in figure 4.**
- 6. Re-install your seat and adjust to your liking.**

## **GET ON YOUR BIKE & RIDE**

**\*\*PERIODICALLY\*\* CHECK THE SCREWS ON PADS BECAUSE VIBRATION  
MAY CAUSE SCREWS TO LOOSEN**



